



## 2019+ Honda Talon X/R Lower Front Door Kit

Covers installation of PN: WCF102025



1. On the inside of the door, remove eight Phillips screws to remove the factory door skin.



2. Drill four ¼" horizontal holes into the pre-existing factory markings.



3. From the inside, insert two 1.5" long bolts with washers into the two holes towards the front of the door. Insert two 7/8" bolts with washers into two holes towards the back of the door. Make sure the door is pushed up tight.
4. Use the new lower door as a template to drill 3 vertical holes.



5. Insert 7/8" bolts in the remaining 3 holes. Make sure all washers, nuts and bolts are in and tighten.



6. Reinstall the door skin.



Any Questions, Comments, or Feedback?

Reach us by Email- [Sales@wcfab.com](mailto:Sales@wcfab.com)

Or the shop phone- 630-277-8239

Thank you for purchasing from Wehrli Custom Fabrication!