



2019+ Honda Talon X/R 2 Seat Rock Sliders and Tree Kickers

Covers installation of PN: WCF102011, WCF102007



1. Remove all push pins (12 outside and 4 inside) that hold the rocker on - bottom door edge, under rocker, wheel well, and inner floor.





2. Remove skid plate for access to front frame area (M10 bolts).



3. Remove three 5 mm Allen bolts and four M10 bolts securing rocker.



4. Use an air saw/sawzall /hack saw to cut rocker using factory cutout lines.



5. Reinstall plastic rocker cover from front wheel well first.





6. Install bar using four long bolts (M12) in front to locate and hold up (don't use nuts here until back is started).



7. Use four short bolts to secure bar at rear.



8. Add nuts at the front (M13).



9. Do not tighten either side until all are started.

10. Work front to back to tighten assembly up.



11. Crack a beer and admire your work.

Any Questions, Comments, or Feedback?

Reach us by Email- Sales@wcfab.com

Or the shop phone- 630-277-8239

Thank you for purchasing from Wehrli Custom Fabrication!